



# KITFOX HARNESS ATTACHMENT

01/95 DRWG.3575-B

LOOKING DOWN ON COCKPIT FROM REAR

© 2002 BRS INC.

DRAWING BY  
JEFF PELTIER

Rev.A 7/98

- 1 Attach one end of each Kevlar (black heatshrink) Harness to front spar carry-thru, see detail below, right.
- 2 Route Harnesses to the rear, secure with tie-wraps along the way.
- 3 IMPORTANT: Route Harnesses over TOP of rear carry-thru. May have to make cut-outs in over head to achieve.
- 4 Attach Rear (white heatshrink) Harness to tube junction shown. Wrap route large loop under junction, then pass "free" end of Harness through large loop.
- 5 Connect all 3 Harnesses together with #12 Link.
- 6 Connect Main Kevlar Bridle to Link and route Bridle over right side.

