




DMR-200D: a - exterior; b - the differential relay assembly: 1 - lower plate; 2 - contact plate; 3 - permanent magnets; 4 - contact screw; 5 - bush; 6 - upper plate; 7 - adjustment screw; 8 - armature; 9 - screw; 10 - series wound coil; 11 - stirrup; 12 - spring; 13 - shunt wound coil